EMP P/N - 14001

Maverick Trail/Sport Speed Shifter Fits: 2018-2021 Trail and 2019-2021 Sport

Installation Instructions:

Installation should be performed by a certified technician.

Includes:

1. (1) Speed Shifter

Hardware Kit: No hardware required. Uses stock hardware.

Tools Needed: 1. T27 Torx Bit

Installation:

- 1. Place wheel chocks around the tires to keep the buggy from rolling.
- 2. Remove the shifter knob by loosing the lock nut under the shifter then unscrew the shifter knob
- 3. Using the Torx bit, remove the stock plastic shifter shroud and save the hardware.
- 4. Once the hardware is removed pull the plastic back from the sides. Pull gently and the fasteners will come out.
- 5. Using the stock hardware install the new shifter plate. Note: The threaded clips will need to be squeezed a little to tighten them on the new shifter. In other words, the stock plastic shroud is a little thicker.
- 6. Test the shift pattern and make sure it shifts properly.
- 7. Tighten all the hardware.
- 8. Enjoy your American Made Product.

We Thank you for choosing Extreme Metal Products, LLC.

www.ExtremeMetalProducts.com











