Polaris RZR PRO XP Laminated Glass Windshield P/N: 14139

Fits: 2020-2023 RZR PRO -XP

Installation Instructions:

Includes:

- 1. (1) Windshield (14139)
- 2. (1) Hand Wiper (13180)

Hardware Kit:

- 1. (2) Aluminum Vent Plate Set (Passenger and Drivers Sides, 14139-02)
- 2. (4) 1/4" Thin White Teflon Washers.
- 3. (6) 1/4-20 x 1-1/4" Long Phillips Pan Head Screws-Black
- 4. (6) 1-1/2" x 1/4" Fender Washers-Black
- 5. (4) 1/4-20 x 3/4" Carriage Bolts-Stn Stl.
- 6. (2) 1-3/4" Rubber Coated Straps (COV2913Z1)
- 7. (4) 2" Rubber Coated Straps (COV3313Z1)
- 8. (11) 1/4-20 Flange Bolt-Black.
- 9. (1) U-Shaped Edge Trim x 32" Long (BR-TS75B-32-no bubble)
- 10.(1) Logo Sticker

Tools Needed:

- 1. Phillips Screw Driver
- 2. 7/16" Wrench

Installation should be done by a certified technician.

Installation:

- 1. Install Vent plates on the inside of the windshield using the carriage bolts, Teflon washers and the nylon flange nuts. Tighten the nuts so that there is a little resistance on the washers so they stay in place but will slide. NOTE: There is a vent plate specific to each side. They are close but not the same.
- 2. Slide the edge trim over the bottom of the metal frame. Start on one side and work you way along the bottom.
- 3. Slide the 2" Rubber straps over the side tubes and the 1-3/4" straps over the top horizontal tubes.
- 4. With the help of a friend set the windshield in place. NOTE: f you have a top this will go under the top.
- 5. Bolt the frame in place using the rubber coated straps, screws and nuts.

 The large washers will go in the front.
- 6. There are two knock-outs for the hand operated wiper. One on the top of the glass and one on the driver's side of the glass. Where you mount the wiper is your preference. Follow the directions on the wiper box to install the wiper.



