

**“Cooter Brown” RZR Cargo Cover**  
**P/N: EMP-10724**  
**Fits: RZR and RZR-S (will not fit RZR-4)**

**Includes:**

1. (1) Cargo Cover
2. (1) Cargo Door
3. (4) Tie Down Plungers (with eyebolt)
4. (2) Southco F7-510 Latch
5. (2) Southco F7-517 Catch
6. (10) 1” Diameter Plugs (CCF-1-1/8”-14-20)
7. (1) Rear Bracket (10724-02)
8. (1) 1/8” x 1” x 25ft Roll of Gasket
9. (6) 10-24 x 5/8” Pan Head Screws
10. (12) 1/4 x 1” Black Flange HD Bolts
11. (10) 1/4” Nylon Nuts
12. (4) Tie-Down Brackets (10724-91)

**Installation:**

If you have an RZR-S you will have to remove the rear cage before installation.

1. Using 10-24 screws attach the latches to the lid and cargo cover (see picture).
2. Install (4) Tie Down Plungers with the eyebolts into the four outer holes. These will go into the holes in the cargo area of your RZR and be tightened by turning after installation. You will have to take them apart and the washers will go on top of the cover (see picture).
3. Stick the gasket around the outer perimeter of the cargo box. They you the remaining gasket around the inside of the cargo lid.
4. Attach the lid to the cargo cover using the 1/4 bolts and nuts.
5. Attach the rear bracket to the two holes in the rear of the cargo cover using the 1/4” bolts (see picture).
6. Attach the Tie down brackets using the remaining 1/4” bolts and nuts (see picture).
7. Now, you can install on your RZR. Tighten the plungers by turning the eyebolts.
8. Insert the plugs into the holes in the cargo area to seal them.

