Kawaski Mule Bed Lift

Extreme Metal Products # 12971

<u>Hardware</u> :		<u>Tools Required</u> :	<u>Tools Recommended</u> :
%X 2 ½" U-Bolt	(2)	¾" Socket	Impact Driver
⁵ / ₁₆ -18 X 1 ¾" U- Bolt	(2)	¾" Wrench	3/8" Nut Driver
⁵∕ ₁₆ -18 Flange Nylon Lock Nut	(4)	⁷ ∕ ₁₆ " Wrench	6" Extension for Ratchet
%-16 Flange Nylon Lock Nut	(6)	9/ ₁₆ " Wrench	
¼-20 X 1" Lg. Flange Bolt	(2)	⁹ / ₁₆ " Deep Well Socket	
¼-20 Flange Nylon Lock Nut	(2)	Ratchet	
Tek Screw	(5)	½" Drill Bit	
Zip Ties	(5)	⁵∕₁₅" Drill Bit	
Wire Splice Tap Connector	(3)	Drill	
%-16 X 1" Flange Bolt	(2)	Phillips Screw Driver	
3 ½" Clevis Pin	(1)	Pliers	
1 ¼" Clevis Pin	(1)	9/ ₁₆ " Drill Bit	

(2)

Cotter Pin





WWW.EXTREMEMETALPRODUCTS.COM

Kawaski Mule Bed Lift

Extreme Metal Products # 12971

- ***Leave Nuts Loose until all Nuts are on U-Bolts***
- *** Make Sure All Wiring is Away From Any Moving Part***

Bed Mount Installation:

- 1) Attach bed mount with supplied Tek screws (Refer To Fig. 1 For mounting position and location)
- 2) Remove the two Tek screws from bed rib (Do not remove Tek screw that is in tube this one will not be getting replaced).
- 3) Now drill out the two Tek screw holes with the 5/16" Drill Bit. (Fig. 2)
- 4) Use two 1/2-20 X1 Flange Bolts to attach the bed mount. (Fig. 3)
- 5) After bolting on the mount use the $\frac{9}{16}$ drill bit to drill through the two remaining holes.
- 6) Once holes are drilled using the two %-16 X 1" flange bolts and the two %-16 flange nuts attach the bed mount to the bed through the two holes previously drilled. (Fig.12)

Frame Mount Installation:

- 1) Place the frame mount in place. (Refer to Fig. 4 For mounting position and location)
- 2) Using the two 2 ½"U-Bolts and %-16 Nuts loosely attach the bottom.
- 3) Using the two 1 ¾" U-Bolts and ¾-16 Nuts loosely attach the top.
- 4) After verifying placement tighten all U-Bolts and Nuts equally. (Fig. 5)
- 5) Install actuator.

Wiring Harness Installation:

- 1) Remove battery cover. (Fig. 6)
- 2) Mount Relays with remaining two Tek screws. (Fig. 7)
- 3) Remove center floorboard cover to expose factory wiring channel. (Fig. 8)
- 4) Run wires from relay to switch through the wiring channel. (Fig. 9)
- 5) Continue running wires under the dash.
- 6) Using the 1/2" drill bit drill hole under Diff. Lock Lever. (Fig. 10)
- 7) Place switch through hole secure with included nut on switch.
- 8) Screw on protective cover over switch. (Fig.11)
- 9) Plug in actuator.
- 10) Connect wiring harness to battery.
- 11) After verifying bed lifts up and down close wiring cover and zip tie any loose wiring up out of the way of any moving parts.









Kawaski Mule Bed Lift

Extreme Metal Products # 12971



















